



updated 28.03.2012
application version: 00.270911

PROGRAMMING MANUAL ZeelProg PDCI-11V(T)

Supported control units: **PDCI-11V, PDCI-11VT**

ZeelProg is PC application for programming ZEELTRONIC engine *control units*.
For programming special PC-USB programmer is needed.

- **ZeelProg** automatically detects PC-USB programmer connection and enables all functions (without PC-USB programmer, **ZeelProg** application is locked).
- **ZeelProg** automatically detects type of engine *control unit* connected to PC-USB programmer.

CONTENT

<i>ZeelProg</i> SOFTWARE INSTALLATION GUIDE	3
<i>ZeelProg</i> USER INTERFACE	3
<u>Auto detection</u>	3
<u>Menu structure</u>	4
<u>Ignition Parameters</u>	5
<u>Misc Parameters</u>	6
<u>Solenoid Parameters</u>	7
<u>PV Parameters</u>	8
<u>Power Jet 1 Parameters</u>	9
PROGRAMMING AND SETTING NEW PARAMETERS	10
<u>Changing control unit parameters</u>	10
<u>Make new *.zee file without connecting control unit</u>	10
<u>Set TPS close position</u>	10
<u>Set TPS open position</u>	11
<u>Set PV close position</u>	11
<u>Set PV open position</u>	12
MONITOR FUNCTION	12

ZeelProg SOFTWARE INSTALLATION GUIDE

CD content:

- driver (USB programmer driver)
- NET Framework
- ZeelProg

Software can be also downloaded from web site:

<http://www.zeeltronic.com/page/zeelprog.php>

ZeelProg application can be installed on Windows XP/Vista.
"NET Framework 3.5" needs to be installed.

Installation:

- ① Insert CD-ROM and browse content.
- ② Install USB programmer driver with running "CDM20600.exe" from CD-ROM "driver" directory.
- ③ Install **ZeelProg** with running "setup ZeelProg.exe" from CD-ROM "ZeelProg" directory.


If **ZeelProg** does not start, install "NET Framework" from CD-ROM "NET Framework" directory.

ZeelProg USER INTERFACE


Auto detection

Zeelprog automatically detects USB-Programmer and type of *control unit*.


⇒ Programmer connected, product (*control unit*) connected:




⇒ Programmer connected, product (*control unit*) not connected:



⇒ Programmer connected, product (*control unit*) not supported:




⇒ Programmer not connected, product (*control unit*) not connected:



Menu structure



⇒ **File menu** is active when PC-USB programmer is connected



- Open** → Open an existing *.zee file
- Save As** → Save all parameters to *.zee file

⇒ **Monitor** is active when *control unit* is connected to PC-USB programmer. Clicking on the **Monitor** opens Monitor window.



⇒ Clicking on **About** opens About window and show some basic information about **ZeelProg** application.



Ignition Parameters

Ignition Parameters

Ignition Map #1

12 Nr. of Points

TPS 100%												
Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	Point 9	Point 10	Point 11	Point 12	
1500	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	RPM
15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	deg

TPS 66%												
Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	Point 9	Point 10	Point 11	Point 12	
1500	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	RPM
15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	deg

TPS 0-33%												
Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	Point 9	Point 10	Point 11	Point 12	
1500	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	RPM
15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	deg

Ignition Map #2

12 Nr. of Points

TPS 100%												
Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	Point 9	Point 10	Point 11	Point 12	
1500	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	RPM
15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	deg

TPS 66%												
Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	Point 9	Point 10	Point 11	Point 12	
1500	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	RPM
15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	deg

TPS 0-33%												
Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	Point 9	Point 10	Point 11	Point 12	
1500	3000	4000	5000	6000	7000	8000	9000	10000	11000	12000	13000	RPM
15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	15,0	deg

Ign. Map Switch

1 Select Ignition Map

34,0 Static Angle [°]

0,0 Advance [°]

30 Delay Compensation [us]

- ⇒ **Nr. of Points** for each ignition map can be set from 4 to 12.
- ⇒ **RPM** of each ignition point can be set from 100rpm to 2000rpm in 100rpm steps.
- ⇒ **deg**...advance of each ignition point can be set from 0deg to 85deg in 0,1deg steps
- ⇒ **Static Angle** is pickup advance position from TDC (Top Dead Centre)
- ⇒ **Advance**...advances, or retards whole ignition map from -10deg to 10deg in 0,1deg steps. Positive value advances and negative value retards.
- ⇒ **Delay Compensation**...ensure correct ignition angle through whole revs. Default value is 30us.
- ⇒ **Ignition Map Switch**...enables, or disables ignition map switch. Ignition map can be selected with switch, when function is enabled.
- ⇒ **Select Ignition Map**...selection is active only when **Ignition Map Switch** is not enabled.

Misc Parameters

Misc

1 Pulses per Rev

15000 Rev Limit [rpm]

12000 Shift Light [rpm]

TCT mode

Throttle Position Sensor

TPS Enable

Calibrate 230 TPS closed (0%)

Calibrate 950 TPS opened (100%)

Quick Shift

Smart Shift

60 Kill Time [ms]

Stop Switch Mode

Low Level Stop

High Level Stop

- ⇒ **Pulses per Rev**...set to 1 for single cylinder and set to 2 for wasted spark twin cylinder.
- ⇒ **Rev limit**...limits maximum revolutions. Set to maximum 20000rpm in 100rpm steps.
- ⇒ **Shift light**...activate shift light output above programmed revs. Set to maximum 20000rpm in 100rpm steps.
- ⇒ **TCT mode**... Throttle Close spark Termination mode, reduces number of sparks above 8000rpm (spark is active every third revolution), when throttle is closed. TCT mode ensure better engine cooling.
- ⇒ **TPS Enable**... enable, or disable TPS (Throttle Position Sensor).
- ⇒ **TPS closed [0%]**... for correct TPS operation, TPS close position must be calibrated!
- ⇒ **TPS opened [100%]**... for correct TPS operation, TPS open position must be calibrated!
- ⇒ **Smart Shift**... enable, or disable Smart Shift. Smart shift function automatically adjusts kill time for different revs. Shift kill time must be always set, as basic kill time.
- ⇒ **Kill Time**... for shifting without using clutch - shift sensor is required. Function is disabled with setting to 0ms.
- ⇒ **Stop Switch Mode: Low Level Stop**... engine stops with low level signal (stop switch connected to the ground)
- ⇒ **Stop Switch Mode: High Level Stop**... engine stops with high level signal (stop switch is opened)

Solenoid parameters

Solenoid Output

Output Type
 Power Jet 2
 Duty Solenoid

Power Jet 2

1 [rpm] 2

	OFF	OFF	OFF
4	<input type="text" value="100"/>	OFF	ON
TPS [%]	<input type="text" value="0"/>	OFF	OFF
3		OFF	OFF

Duty Solenoid

TPS 67-100%								
Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	RPM
<input type="text" value="2000"/>	<input type="text" value="10600"/>	<input type="text" value="11500"/>	<input type="text" value="12900"/>	<input type="text" value="13000"/>	<input type="text" value="13100"/>	<input type="text" value="13200"/>	<input type="text" value="13300"/>	<input type="text" value=""/>
<input type="text" value="0"/>	<input type="text" value="46"/>	<input type="text" value="54"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value=""/>

TPS 34-66%								
Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	RPM
<input type="text" value="2000"/>	<input type="text" value="10600"/>	<input type="text" value="11500"/>	<input type="text" value="12900"/>	<input type="text" value="13000"/>	<input type="text" value="13100"/>	<input type="text" value="13200"/>	<input type="text" value="13300"/>	<input type="text" value=""/>
<input type="text" value="0"/>	<input type="text" value="46"/>	<input type="text" value="54"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value=""/>

TPS 0-33%								
Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	RPM
<input type="text" value="2000"/>	<input type="text" value="10600"/>	<input type="text" value="11500"/>	<input type="text" value="12900"/>	<input type="text" value="13000"/>	<input type="text" value="13100"/>	<input type="text" value="13200"/>	<input type="text" value="13300"/>	<input type="text" value=""/>
<input type="text" value="0"/>	<input type="text" value="46"/>	<input type="text" value="54"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value=""/>

⇒ **Solenoid Output Type...** Solenoid output function can be configured as Power Jet 2, or Duty Solenoid. Duty solenoid is used for adjusting A/F ratio on some carburetors.

- ① **Power Jet 2 'ON' rpm...** revs for activating Power Jet 2
- ② **Power Jet 2 'OFF' rpm...** revs for deactivating Power Jet 2
- ③ **Power Jet 2 'ON' TPS...** throttle position for activating Power Jet 2
- ④ **Power Jet 2 'OFF' TPS...** throttle position for deactivating Power Jet 2

⇒ **RPM** of each Duty Solenoid point can be set from 100rpm to 20000rpm in 100rpm steps.

⇒ **%** of each Duty Solenoid point can be set from 0% to 100%.

Power Jet 2 example:

Power jet 2 ON (RPM) = 5000rpm

Power jet 2 OFF (RPM) = 8000rpm

Power jet 2 ON (TPS) = 0%TPS

power jet 2 OFF (TPS) = 100%TPS

Power jet is switched on when revs are between 5000-8000rpm and throttle position is between 0-100%, otherwise power jet is switched off.

PV PARAMETERS

PV Parameters

PV map #1

4 **Nr. of Points**

Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	RPM
8000	8800	9500	10100	13000	13100	13200	13300	
0	60	60	100	100	100	100	100	%

PV map #2

4 **Nr. of Points**

Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	RPM
8000	9000	10500	11100	13000	13100	13200	13300	
0	40	60	100	100	100	100	100	%

PV map #3

3 **Nr. of Points**

Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	RPM
8000	9000	11000	12900	13000	13100	13200	13300	
0	50	100	100	100	100	100	100	%

PV map #4

8 **Nr. of Points**

Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	RPM
7700	8000	10000	12900	13000	13100	13200	13300	
0	50	100	100	100	100	100	100	%

PV map #5

8 **Nr. of Points**

Point 1	Point 2	Point 3	Point 4	Point 5	Point 6	Point 7	Point 8	RPM
8000	9000	10000	12900	13000	13100	13200	13300	
0	50	100	100	100	100	100	100	%

Power-up Test

PV Map Switch

1 **Select PV Map**

390 **Close Position**


670 **Open Position**

2 **Deviation +-**

- ⇒ **Nr. of Points** for each PV map can be set from 2 to 8.
- ⇒ **RPM** of each PV point can be set from 100rpm to 2000rpm in 100rpm steps.
- ⇒ **%...PV position** of each PV point can be set from 0% to 100% in 1% steps.
- ⇒ **Power-up Test**...enables, or disables PV test at switching on power supply.
- ⇒ **Select PV Map**...selecting active PV map.
- ⇒ **Deviation**...prevents 'hunting' of PV servo.
- ⇒ **Close Position** of PV servo. Close position is 0% on PV map.
- ⇒ **Open Position** of PV servo. Open position is 100% on PV map.
- ⇒ **Test Close**...clicking on **Test Close** button, opens Test Close window. Function is active when PC-USB programmer and *control unit* are connected.
- ⇒ **Test Open**...clicking on **Test Open** button, opens Test Open window. Function is active when PC-USB programmer and *control unit* are connected.
- ⇒ **PV Map Switch**...enables, or disables PV map switch. PV map can be selected with switch, when function is enabled.

8

POWER JET 1 PARAMETERS



⇒ **Power Jet 1 mode** ... select simple, or advanced power jet mode

Power Jet 1 Simple Mode:

- ① ... revs for activating Power Jet 1
- ② ... revs for deactivating Power Jet 1
- ③ ... throttle position for activating Power Jet 1
- ④ ... throttle position for deactivating Power Jet 1

Power Jet 1 Advanced Mode:

- ⑤ ... rev points
- ⑥ ... upper TPS range
- ⑦ ... check for switching 'on' and uncheck for switching 'off' power jet 1

PROGRAMMING AND SETTING NEW PARAMETERS

- ➔ While programming or reading, *control unit* does not need to be connected to power supply, because it is supplied through PC-USB programmer.

Changing control unit parameters

- ① Read parameters from connected *control unit*, by pressing **Read** button.



Progress bar indicate read and verify process.

Successful reading is indicated as: 


Error while reading is indicated as: 


If error occurs, then repeat reading.

- ② Change parameters
- ③ Program parameters to connected *control unit*, by pressing **Program** button.



Progress bar indicate program and verify process.


Successful programming is indicated as: 

Error while programming is indicated as: 

If error occurs, then repeat programming.

Make new *.zee file without connecting control unit

- ① Connect PC-USB programmer to PC.
- ② Set parameters
- ③ Save parameters by clicking **Save As** from **File menu**.



TPS Close Position [0%]


For correct operation of TPS function, TPS close position must be calibrated!



TPS close position can be set manually by entering number, or calibrated by clicking on **Calibrate** button.

Using **Calibrate** function is more recommended.

Clicking on **Calibrate** button opens **Calibrate TPS Close Position** window.



- ⇒ to finish calibration: hold throttle at full close position and press **OK** button
- ⇒ to cancel calibration: press **Cancel** button

TPS Open Position [100%]


For correct operation of TPS function, TPS open position must be calibrated!



TPS open position can be set manually by entering number, or calibrated by clicking on **Calibrate** button.

Using **Calibrate** function is more recommended.

Clicking on **Calibrate** button opens **Calibrate TPS Open Position** window.




- ⇒ to finish calibration: hold throttle at full open position and press **OK** button
- ⇒ to cancel calibration: press **Cancel** button

Set PV close position



- ⇒ Clicking on **Test Close** button opens Test Close window.
- Function is active when PC-USB programmer and *control unit* are connected.




- ⇒ PV servo close position can be tested before confirming... PV servo moves to close position, after clicking on **Test** button.
- ⇒ If PV servo can't move to close position then **error 1** will occur. To clear **error 1** change close position and click on **Test** button.
- ⇒ Click on **OK** button to confirm close position, or **Cancel** to keep old close position.

Set PV open position



- ⇒ Clicking on **Test Open** button opens Test Open window.
Function is active when PC-USB programmer and *control unit* are connected.



- ⇒ PV servo open position can be tested before confirming... PV servo moves to open position, after clicking on **Test** button.
- ⇒ If PV servo can't move to open position then **error 1** will occur. To clear **error 1** change open position and click on **Test** button.
- ⇒ Click on **OK** button to confirm open position, or **Cancel** button to keep old open position.

MONITOR FUNCTION

- ⇒ **Monitor** function is active when *control unit* is connected to PC-USB programmer.



Clicking on **Monitor** opens Monitor window.



- ⇒ Monitor show engine revolution, ignition advance angle, PV position, TPS position, selected ignition map, selected PV map, shift light operation, rev limit operation, power jet 1 operation, duty solenoid operation.

NOTES
