




# Wiring diagram RZ350YPVS - PCDI-10VT

## PV servo



- B - BLACK
- Br - BROWN
- L - BLUE
- G - GREEN
- Gr - GREY
- O - ORANGE
- R - RED
- V - VIOLET
- W - WHITE
- Y - YELLOW

